

electra e[®] light your business Manual of e25.N Wireless Doorbell CE RoHS Please read manual carefully before using 1	Thanks for buying this door bell The main advantages of this prodouct are as below: 1.Transmitter with Button Battery 2.Coding Free 3.Easy usage 4.Easy Instllstion 5.36Chime tone 6.500ft working distance 7.3 Level of ring volume(H-M-L) 8.IP55 waterproof class for transmitter 2	Installation: 1.Use the double-sided adhesive stick to the wall (flat surface recommended) Note:Clean the surface before installing. Recommended: 2.Dig a small hole on the wall & fix with screws 3.Plug the Receiver into a regular socket within the operating range. 3	How to erase the program Program button 1. Push and hold the program button on the chime for about 10 seconds (Make sure it's connected with AC power) 2. when the chime rings, the program have been successfully erased. 4	Doorbell is well-pared&ready for using: Remote button Program button How to reprogram/add chime 1. Erasing the program memory in the new chime first. 2. Push & hold the Program button on the Chime for about 3-5 seconds then push the remote button twice within 5 seconds. when the chime rings, it's successsfully programmed with the remote. 3.Test the chime to make sure it's programed. 5	Cautions: ◆ Please do not open PCB or repair it without professional guide in order to avoid breakdown of components ◆ Please make sure it is not exposed to the sun and rain for a long time or closed to the metallic object ◆ Operating range may be affected by environmental factors and interference sources nearby. ◆ Proper use will prolong life span of wireless doorbell effectively. Technical Specifications: ◆ Receiver Rated voltage: AC 220V ◆ Receiver Standby current: <5mA ◆ Receiving sensitivity: -107dBm ◆ Power Consumption of transmitter : <10mw 6	Warranty : We provide 24 month warranty against any manufacturing defect from the date of your original purchase. electra e[®] light your business 7
electra e[®] light your business Manual Campainha sem fios e25.N CE RoHS Por favor leia o manual antes de usar 1	Obrigado por comprar a campainha sem fios e25.N As principais vantagens deste produto são: 1.Botão transmissor com bateria 2.Codificação livre 3.Fácil utilização 4.Fácil instalação 5.36 toques diferentes 6.Alcance aproximado 150 Metros 7.3 níveis de volume (H-M-L) 8.Botão IP55 2	Instalação: 1.Utilize a fita de dupla face (superficie plana recomendada) Nota: Limpe a superficie antes de instalar Recomendado: 2. Efetuar um pequeno orificio na parede e fixar com parafusos 3. Ligue o recetor a uma tomada dentro da distancia recomendada 3	Botão de programação Botão de programação 1.Mantenha pressionado o botão de programação durante 10 segundos (Certifique-se que o recetor esta ligado a corrente) 2. Quando a campainha tocar, o programa foi apagado com 4	A campainha está preparada e pronta para usar: Botão remoto Botão de programação Como reprogramar / adicionar campainha 1.Apagar a memória do programa da nova campainha 2.Mantenha pressionado o botão do programa na campainha cerca de 3-5 segundos e pressione o botão remoto duas vezes no espaço de 15 segundos. Quando a campainha tocar significa que esta emparelhada com o botão remoto. 3.Teste a campainha para se certificar de que está programada 5	Precauções: ◆ Por favor, não abra a PCB ou tente reparar-la sem a ajuda de um profissional para evitar a quebra de componentes ◆ Certifique-se de que não está exposto ao sol e chuva por um longo período de tempo ou fechado dentro de um componente metálico ◆ O alcance pode ser afetado por fatores ambientais e fontes de interferência nas proximidades ◆ O uso adequado prolongará a vida útil da campainha sem fios Especificações técnicas: ◆ Tensão de alimentação: AC 220V ◆ Consumo em stand by do recetor: < 5mA ◆ Sensibilidade: - 107dBm ◆ Consumo do transmissor: < 10mA 6	Garantia Nós fomecemos garantia de 24 meses a partir da data da sua compra original. Contra qualquer defeito de fabrico electra e[®] light your business 7